





| | | | | | |
|---|---|--|----------------|---------------|-------------------|
|  | Octophon F630 TDM 16 Funktionstasten, LCD 2-zeilig, Freisprechen, Wandmontage Морóженое Синева | <table border="1"> <tr><td>Telekom</td></tr> <tr><td>Перестроенный</td></tr> <tr><td>S30817-S7307-A101</td></tr> </table> | Telekom | Перестроенный | S30817-S7307-A101 |
| Telekom | | | | | |
| Перестроенный | | | | | |
| S30817-S7307-A101 | | | | | |
|  | Octophon F630 TDM 16 Funktionstasten, LCD 2-zeilig, Freisprechen, Wandmontage Морóженое Синева | <table border="1"> <tr><td>Telekom</td></tr> <tr><td>Новый</td></tr> <tr><td>S30817-F7307-A101</td></tr> </table> | Telekom | Новый | S30817-F7307-A101 |
| Telekom | | | | | |
| Новый | | | | | |
| S30817-F7307-A101 | | | | | |
|  | Octophon F630 TDM 16 Funktionstasten, LCD 2-zeilig, Freisprechen, Wandmontage Лáva | <table border="1"> <tr><td>Telekom</td></tr> <tr><td>Перестроенный</td></tr> <tr><td>S30817-S7307-A103</td></tr> </table> | Telekom | Перестроенный | S30817-S7307-A103 |
| Telekom | | | | | |
| Перестроенный | | | | | |
| S30817-S7307-A103 | | | | | |
|  | Octophon F630 TDM 16 Funktionstasten, LCD 2-zeilig, Freisprechen, Wandmontage Лáva | <table border="1"> <tr><td>Telekom</td></tr> <tr><td>Новый</td></tr> <tr><td>S30817-F7307-A101</td></tr> </table> | Telekom | Новый | S30817-F7307-A101 |
| Telekom | | | | | |
| Новый | | | | | |
| S30817-F7307-A101 | | | | | |